



Fosmon LED Shake Shake Baby Night Light with 4 Color Modes – White



DO NOT RETURN THE PRODUCT

There are good days and there are bad days. If there is a problem with your product, or if you are unhappy with it, we apologize for our mistake. PLEASE GIVE US A CHANCE and WE WILL MAKE IT RIGHT.

1-833-3-Fosmon (833-336-7666)

(612) 435-7508

support@fosmon.com

Thank you for purchasing this Fosmon product. For optimum performance and safety, please read this user manual carefully before operating and keep it for future reference.

Fosmon's Shake Shake Baby Night Light will accompany your baby with numerous color modes and make them feel safe at night.

Package Includes

- 1x Shake Shake Night Light
- 1x Night Light Stand
- 1x Micro-USB Cable
- 1x User Manual


Specifications

Dimensions	77x120 mm
Materials	ABS (Acrylonitrile butadiene styrene), PC (Polycarbonates), Steel Balls
Power Rating	3W
Input	5V-1A
Charging Time	2.5 hours
Working Time	5.5 hours for Maximum Brightness 150 hours for Minimum Brightness 80 hours for Shake Shake Mode 55 hours for Dynamic Mode
LED Quantity	SMD2835 x18 + RGB5050 x4
Color Temp	2700-6500K


Features

MODE	OPERATION	FEATURE
Turn ON/OFF the Light	Long Press for 3 Seconds	The light will turn on/off.
Dimming Mode	Short Press (1st mode)	Smart touch ((1)(2)(3) (on diagram)) for color dimming.
Sleeping Mode	Short Press (2nd mode)	The light will be on minimum brightness.
Shake Shake Mode	Short Press (3rd mode)	RGB colors will change synchronously with how fast you shake the night light. Steel balls will rattle and sound as you shake. The colors will stop changing in 10 seconds after the shaking stops.
Dynamic Mode	Short Press (4th mode)	RGB lights gradually changes colors cyclically.
Turn OFF the Light	Long Press for 3 Seconds	The light can be turned off in every mode.

Product Diagram



Product Front



Product Back

Caution

1. Long periods of reading in bed with this light may be harmful to your eyes.
2. If the light does not turn on or properly function, power it back off and back on or recharge it with the provided micro-USB to make sure it has a full charge.
3. Do not open the light as you could harm yourself or damage the product and cease its functionality.
4. Do not place the light in or next to extreme heat sources, moisture or corrosive substances.

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Operation Notes

1. Continually touching (2) will change the white light to a warm light. Continually touching (3) will change the warm light into a white light.
2. While in Dimming Mode, when you reach the minimum or maximum brightness settings through the dimming (2)(3) touch controls, the (4) LED indicator will blink green.

Modes/Operation Order

Turn ON the Light > Warm & Cool Dimming Mode > Sleeping Mode > Shake Shake Mode > Dynamic Mode > Turn OFF the Light

Battery Notes

1. Before using, plug in the micro-USB and charge the night light. If the (4) LED indicator turns green, this indicates that the light is fully charged. A full charge takes about 2.5 hours.
2. (4) LED indicator will blink red when the battery is low (3.2V-3.4V).
3. When the battery is lower than 3.2V voltage, the light will automatically turn off.
4. Connect the provided micro-USB cable to charge the device. The (4) LED indicator will turn green to indicate a full charge.

Limited Lifetime Warranty

Visit fosmon.com/warranty for Product Registration, warranty and limited liability details.

Recycling the Product

To dispose this product properly, please follow the recycling process regulated in your area.

Follow Us On Social Media



www.fosmon.com
support@fosmon.com
© 2020 Fosmon Inc. All rights reserved.